


Installation Instructions for Water Trap

- Mount Water Trap at least 12-inches below ozone generator making sure that it is not above any electrical or mechanical equipment.
- Ensure that water flowing out of the Water Trap can escape to a drain. If mounted inside an enclosure, drill a ½-in diameter hole in the lowest part of the enclosure.



Ozone gas travels from the ozone generator through the teed adapter and into the horizontal Teflon tubing. The closed valve (not shown) on the water trap prevents ozone from escaping into the atmosphere.

